

# 1949-52 BUMPERS, BUMPER BOLTS, BUMPER BOLT KITS

## 1949-52 FRONT 1-PIECE BUMPER



Chromed and ready to install!

ORDER #6482  
\*Oversize Shipping

**\$350<sup>00</sup>**

## 1949-52 REAR 1-PIECE BUMPER

Just like the front — ready to go



ORDER #6483  
\*Oversize Shipping

**\$350<sup>00</sup>**

## HIGH DOME BUMPER BOLT

Original bumper bolt used on cars.  
Chrome finish.

ORDER #520HD

**\$4<sup>00</sup>** ea.

## 1/2" POLISHED STAINLESS CAP BUMPER BOLT

ORDER #520 **\$2<sup>00</sup>** ea.

## FRONT OR REAR BUMPER BOLT KIT

Uses replacement 1/2" stainless capped bolt.  
Bolt is not stainless.

ORDER #1917

**\$10<sup>00</sup>** ea.

## FRONT OR REAR BUMPER BOLT KIT

Uses original high dome bolt.

ORDER #1904

**\$16<sup>00</sup>**

## 1949-52 FRONT BUMPER ASSEMBLY KIT

ORDER #5905

**\$24<sup>00</sup>**

## 1949-52 REAR BUMPER ASSEMBLY KIT

ORDER #1902

**\$24<sup>00</sup>**

## 1949-52 FRONT BUMPER ASSEMBLY KIT

Uses replacement 1/2" steel bolt with stainless cap.

ORDER #5905-1

**\$16<sup>00</sup>**

## REAR BUMPER ASSEMBLY KIT

ORDER #1919

**\$16<sup>00</sup>**

## REAR BUMPER ARM GROMMETS

ORDER #4601-9

**\$9<sup>00</sup>** pr.

## FRONT SPLASH PAN PLUG

ORDER #4601-10

**\$6<sup>00</sup>** pr.

## 1949-50 FRONT LICENSE POCKET GUARD

Excellent reproduction.



ORDER #4540

**\$150<sup>00</sup>**

# 1953-54 BUMPERS, BUMPER BOLTS, BUMPER BOLT KITS

## 1953 1-PIECE FRONT BUMPER

Chrome plated, excellent quality  
- ready to install.

ORDER #482



**\$375<sup>00</sup>**

\*Oversize Shipping

## 1954 1-PIECE FRONT BUMPER

Ready to install.

ORDER #483

**\$375<sup>00</sup>**

\*Oversize Shipping



## 1953 or 1954 1-PIECE REAR BUMPER

Chromed and ready to install.

ORDER #484



**\$375<sup>00</sup>**

\*Oversize Shipping



## 1/2" HIGH DOME CHROME BUMPER BOLT

Original bumper bolt used on cars.  
Chrome finish.

ORDER #520 HD **\$4<sup>00</sup>** ea.



## 1/2" POLISHED STAINLESS CAP BUMPER BOLT

ORDER #520 **\$2<sup>00</sup>** ea.



## FRONT OR REAR BUMPER BOLT KIT

Uses original high dome bolt.

ORDER #1904  
**\$16<sup>00</sup>**



## FRONT OR REAR BUMPER BOLT KIT

Uses replacement 1/2" stainless capped bolt. Bolt is not stainless.

ORDER #1917  
**\$10<sup>00</sup>**

## 1953 OR 1954 FRONT BUMPER ASSEMBLY KIT

ORDER #1902

**\$24<sup>00</sup>**



## 1953 - 1954 REAR BUMPER ASSEMBLY KIT

ORDER #1901  
**\$24<sup>00</sup>**

## 1953-1954 FRONT CLIP ASSEMBLY KIT

Contains all bolts, nuts, washers, etc.  
to reassemble front clip.  
(Fenders, inner fenders)

ORDER #1905 **\$20<sup>00</sup>**



## 1953 OR 1954 FRONT BUMPER ASSEMBLY KIT

Uses replacement 1/2" stainless capped bolt. Bolt is not stainless.

ORDER #1918

**\$16<sup>00</sup>**



## 1953 OR 1954 REAR BUMPER ASSEMBLY KIT

Cap only assembly kit.

ORDER #1919  
**\$16<sup>00</sup>**

